USER'S GUIDE
V: 883-01

# ITB283B

## Bluetooth 32" HD Sound Bar

For the most up-to-date version of this User's Guide, go to **www.iLiveElectronics.com**

# Warnings and Precautions

**CAUTION**: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

**WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

**AVERTISSEMENT:** Pour réduire le risque d'incendie ou de choc électrique, ne pas exposer cet appareil sous la pluie et l'humidité.

**CAUTION:** Use of any controls or adjustments or performance of procedures other than those herein specified may result in hazardous radiation exposure.

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.

**WARNING:** Use of this unit near fluorescent lighting may cause interference regarding use of the remote. If the unit is displaying erratic behavior move away from any fluorescent lighting, as it may be the cause.

**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

***PRÉCAUTION:*** *Danger d'explosion si les piles sont remplacées de façon incorrect. Remplacer les piles seulement par le même type de pile ou l'équivalent.*

**WARNING:** The battery, batteries, and battery pack shall not be exposed to excessive heat such as sunshine, fire, or the like.

**WARNING:** Lithium batteries, like all rechargeable batteries are recyclable and should be recycled or disposed of in normal household waste. Contact your local government for disposal or recycling practices in your area. They should never be incinerated since they might explode.

**WARNING**: Shock hazard - Do Not Open.

***AVIS****: RISQUE DE CHOC ÉLECTRIQUE - NE PAS OUVRIR*

Mains Plug or Direct plug-in adapter is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the Mains Plug or Direct plug-in adapter should be disconnected from the mains socket outlet completely.

*La fiche d'alimentation ou adaptateur de courant est utilisé comme dispositif de déconnexion et doit rester accessible pendant l'utilisation. Pour mettre l'appareil hors tension, la fiche ou adaptateur de courant doit être débranché de la prise de courant.*

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

# Important Safety Instructions

1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding - type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.

12.

Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

**WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.

## FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Additional Warnings

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
*L'appareil ne doit pas être exposé aux écoulements ou aux éclaboussures et aucun objet ne contenant de liquide, tel qu'un vase, ne doit être placé sur l'objet.*

Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
*Les piles ne doivent pas être exposées à de forte chaleur, tel qu'à la lumière du soleil, au feu ou autres choses de semblable.*

Caution marking is located at the rear or bottom of the apparatus.
*Attention marquage est situé sur le paneau arrière ou inférieur de l'unité.*

The marking information is located at the rear or bottom of apparatus.
*Le marquage est situé sur le paneau arrière ou inférieur de l'unité.*



This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

# ITB283B

## Features

- 37″ length
- Supports Bluetooth v2.0
- Supports Enhanced Data Rate (EDR)
- Supports profile A2DP (Advanced Audio Distribution Profile)
- Digital volume control
- Remote
- Optical digital audio input
- 3.5mm audio input
- RCA stereo audio inputs
- LED source indicators
- LED pairing indicator
- LED power indicator
- Wall mountable
- Wireless range: 33 feet
- Built-in stereo speakers
- Cloth speaker grill
- AC power input: requires an AC/DC power adapter (included)

## Includes

- Remote control: requires a CR2025 battery (pre-installed)
- RCA stereo audio cable
- Wall-mount hardware and instructions
- AC/DC power adapter

# Setup

## Power

AC power input: requires an AC/DC power adapter (included)



## Remote

Requires a CR2025 battery (pre-installed)




## LED Indicators

| Status | Indicator |
|---|---|
| Power Off | Red Light |
| Optical Mode | Amber Light |
| Aux In Mode | White light |
| Line In Mode | Green Light |
| Bluetooth Ready | Flashing Blue Light |
| Bluetooth Connected | Blue Light |

## Mounting

We recommend having this bar speaker professionally mounted.

# Table of Contents

**Warnings and Precautions** . . . . . 2

**Important Safety Instructions** . . . . . 3

**ITB283B** . . . . . 4
Features

**Setup** . . . . . 4
Power
LED Indicators
Remote
Mounting
Includes

**Table of Contents** . . . . . 5

**Introduction** . . . . . 6

**Audio Inputs** . . . . . 8
Using the Stereo RCA Inputs
Using the Optical Input

**Line In** . . . . . 9
Using the Line In

**Bluetooth** . . . . . 10
Pairing a Bluetooth Device for the First Time

**Bluetooth** . . . . . 11
Playing Audio Wirelessly

**Company Information** . . . . . 12
International Support
Contact Information
Warranty
Green Initiative

# Introduction




**Stereo RCA Audio Inputs** **Optical Input** **DC Power Input**




**Power**
Press to turn the unit on or off.

**Source**
Press to switch between Optical, Line In, AUX, and Bluetooth modes.

**Volume**
Press to adjust the volume up or down.

**Pairing**
Press to begin pairing with a Bluetooth device.

**Line Input**

**Power**
Press to turn the unit on or off.

**Optical**
Press to switch to Optical mode.

**Line**
Press to switch to Line In mode.

**Music**
Press to switch to the EQ optimized for music.

**Treble**
Press to adjust the treble up or down.

**Bass**
Press to adjust the bass up or down




**BT**
Press to switch to Bluetooth Mode.

**Mute**
Press to mute the volume.

**Aux**
Press to switch to AUX mode.

**Talk**
Press to switch to the EQ optimized for dialogue.

**Movie**
Press to switch to the EQ optimized for movie sound.

**Volume**
Press to adjust the volume.

# Audio Inputs

## Using the Stereo RCA Inputs

*When connecting two products using an RCA Cable, match the colored ports with the same colored connection.*

*Before use, disconnect any cables connected to the Line In.*




1. Connect the RCA Cable to the RCA Stereo Inputs located on the back of the unit, and to the audio outputs on the television.
2. Press the **Power** button to power on the unit.
3. Press the **Source** button repeatedly to enter Aux Mode, indicated by a white light.
4. Audio played through the television will now be heard through the speakers.

## Using the Optical Input

*You will need: An audio source with an Optical Audio Output and a Digital Optical Audio Cable (not included)*




1. Connect the Digital Optical Audio Cable to the optical output on the audio source and to the **Optical Input** on the speaker bar.
2. Press the **Power** button to power the unit on.
3. Press the **Source** button repeatedly to switch to SPDIF Mode, indicated by a amber light.
4. Using the native controls on your connected device, make sure the audio settings are set to PCM or Optical Audio and are turned On.
5. Audio from the connected audio source will now be played through the speakers.

# Line In

## Using the Line In

1. Plug one end of a 3.5 mm audio input cable into the **Line In** on the unit.

   *3.5 mm audio input cable not included.*

   *Before use, disconnect any cables connected to the Stereo RCA Inputs.*

2. Plug the other end of the cable into the audio output/headphone output on an MP3 Player or other audio source.
3. Press the **Power** button to power the unit on.
4. Press the **Source** button repeatedly to enter Line In Mode, indicated by a green light.
5. Audio played through the connected device will now be heard through the speakers.

# Bluetooth

## Pairing a Bluetooth Device for the First Time

1. Power on the unit by pressing the **Power** button.
2. Press the **Source** button repeatedly to enter Bluetooth mode, indicated by a blue light.
3. Press the **Pairing** button on the side of the unit.

   *The* **Pairing Indicator** *will flash blue quickly.*

   *When pairing, remain within 3 feet of the unit.*
4. Using the native controls on your Bluetooth device, select the "ITB283" in your Bluetooth settings to pair.

   *If your device requests a password, enter the default password " 0 0 0 0 ".*

   *Refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.*
5. When successfully paired and connected, a beep will issue from the unit and the **Pairing Indicator** will display a solid blue light.

   *After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device.*

   *If your device should become unpaired or you find it is unable to connect, repeat the above steps.*

# Bluetooth

## Playing Audio Wirelessly

1. Follow the instructions for Pairing a Bluetooth Device.
2. Use the native controls on the connected Bluetooth Device to select a track.
3. To play, pause or skip the selected track, use the native controls on the connected Bluetooth Device.
4. Audio played through the connected Bluetooth device will now be heard through the speakers.

# Company Information

## International Support

To download this User's Guide in English, Spanish, and French, or to get answers to frequently asked questions, visit the support section at:
**www.iLiveElectronics.com**

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en:
**www.iLiveElectronics.com**

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur:
**www.iLiveElectronics.com**

## Contact Information

**Email Support:** prodinfo@dpiinc.com
**Email Parts:** partsinfo@dpiinc.com
**Phone Support:** 1-888-999-4215
**Website:** www.iLiveElectronics.com

## Warranty

For Warranty Information and the most up-to-date version of this User's Guide, go to:
www.iLiveElectronics.com

## Green Initiative

MADE GREEN
protect for today • sustain for tomorrow

Environmental Commitment to 'Protect for Today and Sustain for Tomorrow'
On a continual basis DPI, Inc. is making efforts to sustain the environment and improve the recyclability of its products and packaging.

Focusing on "protecting for today and sustaining for tomorrow" DPI, Inc. has committed to reducing packaging size, increasing the usage of recyclable plastics, and ensuring that packaging and manuals are made with up to 85% recycled material. In addition to material consideration, DPI, Inc. has also focused on the finer details that positively impact the environment such as employing the usage of soy-based inks.

DPI, Inc. also ensures that the factories that produce the company's wide variety of consumer electronics adhere to environmentally friendly air and water restrictions. This is yet another example that every step of the way DPI, Inc. is making efforts to lessen any impact on the environment.

In 2011 DPI, Inc. also began conversations with Energy Star in order to ensure that the consumer electronics being produced meet high standards of energy efficiency. The ultimate goal is keeping energy costs for consumers low while providing quality, feature-rich products.

Copyright © 2012 Digital Products International (DPI, Inc.) | All other trademarks appearing herein are the property of their respective owners.
Specifications are subject to change without notice